

Field Inspection – Basic (Drive Axles & Trailer Axles)

A. 1.) Check operation of control unit.



2.) Select off-hwy unloaded setting (lowest pressures) and verify drive tires and trailer tires deflate. A loss of air should be heard.



B. 1.) Check drive axle hardware: valves on, hoses and hardware in place. Valve handles should be in-line with hose when valves are open.



2.) Check trailer axle hardware: valves on, hoses and hardware in place.

